

Note: Both Serial Number and Model Number are Required when Ordering Parts

RECORD SERIAL NUMBER HERE

CATALOG NUMBER

1005 - 001

Customer Service

(800) 548-5438

(858) 578-7676

Fax

(858) 578-9558

CONTENTS

INSTRUCTIONS	02
FRAME ASSEMBLY	04
PRE-ASSEMBLY	23
DECAL PLACEMENT	25
PART LIST	29
ABBREVIATION LISTING	32
BOLT SIZING CHART	33
WASHER SIZING CHART	35
MAINTENANCE SCHEDULE	37
GENERAL MAINTENANCE INFORMATION	38
WEIGHT TRAINING TIPS	40
EXERCISE LOG	41
LIMITED WARRANTY	42

INSTRUCTIONS

Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only HOIST replacement parts when servicing. Failure to do so will void your warranty and could result in personal injury.

HOIST equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized HOIST dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.

TOOLS REQUIRED

Socket Wrench

1/2", 9/16" and 3/4" Sockets

Crescent Wrench


Rubber Mallet

Tape Measure

Level


Allen Wrench Set





FRAME ASSEMBLY STEP 1

ITEM NO.	PART NUMBER	DESCRIPTION	
2	026-01X2475	REAR FOOT ASSEMBLY	
20	026-01P2323	SIDE CROSS-MEMBER	
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)	
33	011-0107026	3/8"-16UNC X 2.25" HHB (WZ)	
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)	




FRAME ASSEMBLY STEP 2

ITEM NO.	PART NUMBER	DESCRIPTION	
2	026-01X2475	REAR FOOT ASSEMBLY	
20	026-01P2323	SIDE CROSS-MEMBER	
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)	
33	011-0107026	3/8"-16UNC X 2.25" HHB (WZ)	
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)	•

NOTE: - HAND TIGHTEN BOLT. - SOME PARTS MAY HAVE BEEN REMOVED FOR CLARITY. 2 33 28 28 38 20


FRAME ASSEMBLY STEP 3

ITEM NO.	PART NUMBER	DESCRIPTION
2	026-01X2475	REAR FOOT ASSEMBLY
3	026-01X2474	UPRIGHT ASSEMBLY (LEFT)
4	026-01X2535	UPRIGHT ASSESMBLY (RIGHT)
20	026-01P2323	SIDE CROSS-MEMBER
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)
30	013-0102028	3/8" CURVED WASHER (WZ)
33	011-0107026	3/8"-16UNC X 2.25" HHB (WZ)
36	011-0407018	3/8"-16UNC X 3.75" HHB (WZ)
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)



FRAME ASSEMBLY STEP 4


ITEM NO.	PART NUMBER	DESCRIPTION	
3	026-01X2474	UPRIGHT ASSEMBLY (LEFT)	
4	026-01X2535	UPRIGHT ASSESMBLY (RIGHT)	
5	026-01X2423	CROSSMEMBER ASSEMBLY	
21	026-01P2419	1.25" X 6.00" BACKING PLATE	
30	013-0102028	3/8" CURVED WASHER (WZ)	
36	011-0407018	3/8"-16UNC X 3.75" HHB (WZ)	
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)	



FRAME ASSEMBLY STEP 5


ITEM NO.	PART NUMBER	DESCRIPTION
3	026-01X2474	UPRIGHT ASSEMBLY (LEFT)
4	026-01X2535	UPRIGHT ASSESMBLY (RIGHT)
5	026-01X2423	CROSSMEMBER ASSEMBLY
30	013-0102028	3/8" CURVED WASHER (WZ)
36	011-0407018	3/8"-16UNC X 3.75" HHB (WZ)
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)






FRAME ASSEMBLY STEP 6

ITEN 4 N 10	DADT NUMBER	DECODIDION
ITEM NO.	PART NUMBER	DESCRIPTION
1	026-01X2439	MAIN FRAME ASSEMBLY
5	026-01X2423	CROSSMEMBER ASSEMBLY
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)
29	013-0102003	1/2" X 27mm SAE FLAT WASHER (WZ)
36	011-0407018	3/8"-16UNC X 3.75" HHB (WZ)
37	011-0107050	1/2"-13UNC X 3.75" HHB (WZ)
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)
39	012-0304011	1/2"-13UNC THIN NYLOCK NUT (WZ)




FRAME ASSEMBLY STEP 7

ITEM NO.	PART NUMBER	DESCRIPTION	
6	026-01X2427	SEAT SLIDE ASSEMBLY	
7	026-01X2426	BACKPAD MOUNT ASSEMBLY	
8	026-01X2424	LINK ASSEMBLY	
22	026-01X2741	PIVOT BRACKET ASSEMBLY	
29	013-0102003	1/2" X 27mm SAE FLAT WASHER (WZ)	
31	011-0107024	5/16"-18UNC X 2.25" HHB (WZ)	
32	011-0407033	5/16"-18UNC X .75" HHB (WZ)	
37	011-0107050	1/2"-13UNC X 3.75" HHB (WZ)	
39	012-0304011	1/2"-13UNC THIN NYLOCK NUT (WZ)	




FRAME ASSEMBLY STEP 8

ITEM NO.	PART NUMBER	DESCRIPTION
6	026-01X2427	SEAT SLIDE ASSEMBLY
7	026-01X2426	BACKPAD MOUNT ASSEMBLY
10	022-01PD2025-A	UPHOLSTERY PAD W/ACX BACKING
26	026-01M0941	BACKPAD LOCKOUT
27	013-0102004	5/16" X 22mm USS FLAT WASHER (WZ)
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)
32	011-0407033	5/16"-18UNC X .75" HHB (WZ)
34	011-0407058	3/8"-16UNC X 2.00" HHB (WZ)
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)
51	013-0602002	3/8" FLAT NYLON WASHER



FRAME ASSEMBLY STEP 9


ITEM NO.	PART NUMBER	DESCRIPTION	
1	026-01X2439	MAIN FRAME ASSEMBLY	
7	026-01X2426	BACKPAD MOUNT ASSEMBLY	
11	022-01PD2040-A	UPHOLSTERY PAD W/ACX BACKING	
27	013-0102004	5/16" X 22mm USS FLAT WASHER (WZ)	
31	011-0107024	5/16"-18UNC X 2.25" HHB (WZ)	
50	026-01X2536	FOOT PEG ASSEMBLY	



NOW THAT THE HF4170 UNIT IS COMPLETELY ASSEMBLED TAKE TIME TO ASSURE THAT YOUR UNIT IS ASSEMBLED SQUARE AND PERPENDICULAR. IF THEY ARE NOT PERPENDICULAR IN BOTH DIRECTIONS, IT WILL BE NECESSARY TO LOOSEN SOME FRAME HARDWARE TO RE-ALIGN THE FRAME AND RETIGHTEN BOLTS.


PRE-ASSEMBLY

ITEM NO.	PART NUMBER	DESCRIPTION
1	026-01X2439	MAIN FRAME ASSEMBLY
3	026-01X2474	UPRIGHT ASSEMBLY (LEFT)
4	026-01X2535	UPRIGHT ASSESMBLY (RIGHT)
5	026-01X2423	CROSSMEMBER ASSEMBLY
6	026-01X2427	SEAT SLIDE ASSEMBLY
7	026-01X2426	BACKPAD MOUNT ASSEMBLY
8	026-01X2424	LINK ASSEMBLY
9	026-01X2421	SAFETY PIN ASSEMBLY
12	020-0007004	KNOB - OVAL
13	026-01X2161	THREADED PULL-PIN ASSEMBLY
14	014-0101002	OILITE FLANGED
15	016-0201034	END CAP-R 2.00" X 3.00" (BLACK)
16	016-0201036	END CAP 1.50" X 2.50" (BLACK)
17	016-0201045	Ø3.00" END CAP (DOMED)
18	019-0001001	PLUG BUMPER
19	020-0011009	SPRING
23	026-01PL0125	E-Z GLIDE PLASTIC SLEEVE
24	026-01PL0257	PLASTIC GUIDE SLEEVE
25	026-01PL2114	PLASTIC SPACER
26	026-01M0941	BACKPAD LOCKOUT
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)
30	013-0102028	3/8" CURVED WASHER (WZ)
35	011-0407069	3/8"-16UNC X 2.75" HHB (WZ)
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)
48	019-0002002	CLOSED END GRIP Ø2.00"
49	016-0201029	Ø2.00" END CAP .06" WALL (BLACK)
50	026-01X2536	FOOT PEG ASSEMBLY



DECAL PLACEMENT

ITEM NO. PART NUMBER DESCRIPTION 1 026-01X2439 MAIN FRAME ASSEMBLY 2 026-01X2475 REAR FOOT ASSEMBLY 3 026-01X2474 UPRIGHT ASSEMBLY (LEFT) 4 026-01X2535 UPRIGHT ASSEMBLY (RIGHT) 5 026-01X2423 CROSSMEMBER ASSEMBLY 6 026-01X2427 SEAT SLIDE ASSEMBLY 40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50" 47 021-0003282 SPOTTER DECAL 1.63" X 3.25"			
2 026-01X2475 REAR FOOT ASSEMBLY 3 026-01X2474 UPRIGHT ASSEMBLY (LEFT) 4 026-01X2535 UPRIGHT ASSESMBLY (RIGHT) 5 026-01X2423 CROSSMEMBER ASSEMBLY 6 026-01X2427 SEAT SLIDE ASSEMBLY 40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003222 DECAL "H" 1.81" X 2.50"	ITEM NO.	PART NUMBER	DESCRIPTION
3 026-01X2474 UPRIGHT ASSEMBLY (LEFT) 4 026-01X2535 UPRIGHT ASSESMBLY (RIGHT) 5 026-01X2423 CROSSMEMBER ASSEMBLY 6 026-01X2427 SEAT SLIDE ASSEMBLY 40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003220 DECAL HOIST 1.63" X 5.94"	1	026-01X2439	MAIN FRAME ASSEMBLY
4 026-01X2535 UPRIGHT ASSESMBLY (RIGHT) 5 026-01X2423 CROSSMEMBER ASSEMBLY 6 026-01X2427 SEAT SLIDE ASSEMBLY 40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	2	026-01X2475	REAR FOOT ASSEMBLY
5 026-01X2423 CROSSMEMBER ASSEMBLY 6 026-01X2427 SEAT SLIDE ASSEMBLY 40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	3	026-01X2474	UPRIGHT ASSEMBLY (LEFT)
6 026-01X2427 SEAT SLIDE ASSEMBLY 40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	4	026-01X2535	UPRIGHT ASSESMBLY (RIGHT)
40 021-0003008 DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69" 41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	5	026-01X2423	CROSSMEMBER ASSEMBLY
41 021-0003113 DECAL PINCH POINT 1.63" X 3.25" (VERTICAL) 42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	6	026-01X2427	SEAT SLIDE ASSEMBLY
42 021-0003135 DECAL COMMERCIAL WARNING 1.50" X 6.69" 43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	40	021-0003008	DECAL COMMERCIAL MAINTENANCE 1.50" X 6.69"
43 SERIAL # DECAL DECAL SERIAL # 1.63" X 2.63" 44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	41	021-0003113	DECAL PINCH POINT 1.63" X 3.25" (VERTICAL)
44 021-0003228 600 LB. WEIGHT RATING DECAL 1.63" X 1.63" 45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	42	021-0003135	DECAL COMMERCIAL WARNING 1.50" X 6.69"
45 021-0003230 DECAL HOIST 1.63" X 5.94" 46 021-0003222 DECAL "H" 1.81" X 2.50"	43	SERIAL # DECAL	DECAL SERIAL # 1.63" X 2.63"
46 021-0003222 DECAL "H" 1.81" X 2.50"	44	021-0003228	600 LB. WEIGHT RATING DECAL 1.63" X 1.63"
	45	021-0003230	DECAL HOIST 1.63" X 5.94"
47 021-0003282 SPOTTER DECAL 1.63" X 3.25"	46	021-0003222	DECAL "H" 1.81" X 2.50"
	47	021-0003282	SPOTTER DECAL 1.63" X 3.25"



DECAL REFERENCE



1-800-548-5438 www.hoistfitness.com

SERIAL # 00-00-000000

SERIAL # DECAL





ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE THE RISK ALWAYS FOLLOW THESE SIMPLE RULES. NJURY OR EVEN DEATH. THERE IS A RISK

CLOSED INSTRUCTIONS before

Take your time and do not rush the rercise. Practice proper breathing,

ers should not use this

021-0003135

		L
ı		
П		ľ
П	7	L
П	\cup	
П		ľ
П		ľ
П		
П	\cup	
П	\leq	
П	$\boldsymbol{<}$	
Ĭ		
- 1		

	Yearly												×
	Months										×	×	
	Monthly								×	×			
	Wookly				×	X	×	×					
٠	$D_{8il_{\mathcal{Y}}}$	×	X	×									
	COMMERCIAL MAINTENANCE	Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack	Clean; Upholstery	Inspect; Cables or Belts and their tension	Inspect; Accessory Bars and Handles	Inspect; All Decals	Inspect; All nuts and Bolts Tighten if Needed.	Inspect; Anti-Skid Surfaces	Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	Clean & Wax; All Glossy Finishes	Repack with Grease Linear Bearings	Replace; Cables, Belts and Connecting Parts.

021-0003008





DECAL REFERENCE



021-0003113



021-0003282



PART LIST
NOTE: SOME OF THESE PARTS MAY COME PRE-INSTALLED

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.		
1	026-01X2439	MAIN FRAME ASSEMBLY	1		
2	026-01X2475	REAR FOOT ASSEMBLY	2		
3	026-01X2474	UPRIGHT ASSEMBLY (LEFT)			
4	026-01X2535	UPRIGHT ASSESMBLY (RIGHT)			
5	026-01X2423	CROSSMEMBER ASSEMBLY	1		
6	026-01X2427	SEAT SLIDE ASSEMBLY	1		
7	026-01X2426	BACKPAD MOUNT ASSEMBLY	1		
8	026-01X2424	LINK ASSEMBLY	1		
9	026-01X2421	SAFETY PIN ASSEMBLY	1		
10	022-01PD2025-A	UPHOLSTERY PAD W/ACX BACKING	1		
11	022-01PD2040-A	UPHOLSTERY PAD W/ACX BACKING	1		
12	020-0007004	KNOB - OVAL	1		
13	026-01X2161	THREADED PULL-PIN ASSEMBLY	2		
14	014-0101002	OILITE FLANGED	8		
15	016-0201034	END CAP-R 2.00" X 3.00" (BLACK)	1		
16	016-0201036	END CAP 1.50" X 2.50" (BLACK)	1		
17	016-0201045	Ø3.00" END CAP (DOMED)	2		
18	019-0001001	PLUG BUMPER	1		
19	020-0011009	SPRING	1		
20	026-01P2323	SIDE CROSS-MEMBER	2		
21	026-01P2419	1.25" X 6.00" BACKING PLATE	2		
22	026-01X2741	PIVOT BRACKET ASSEMBLY	1		
23	026-01PL0125	E-Z GLIDE PLASTIC SLEEVE	2		
24	026-01PL0257	PLASTIC GUIDE SLEEVE	2		
25	026-01PL2114	PLASTIC SPACER	1		
26	026-01M0941	BACKPAD LOCKOUT	1		
27	013-0102004	5/16" X 22mm USS FLAT WASHER (WZ)	4		
28	013-0402007	3/8" X 22mm FLAT WASHER (WZ)	16		
29	013-0102003	1/2" X 27mm SAE FLAT WASHER (WZ)	8		
30	013-0102028	3/8" CURVED WASHER (WZ)	21		
31	011-0107024	5/16"-18UNC X 2.25" HHB (WZ)	2		
32	011-0407033	5/16"-18UNC X .75" HHB (WZ)	2		
33	011-0107026	3/8"-16UNC X 2.25" HHB (WZ)	4		
34	011-0407058	3/8"-16UNC X 2.00" HHB (WZ)	1		
35	011-0407069	3/8"-16UNC X 2.75" HHB (WZ)	1		



PART LIST CONTINUED

NOTE: SOME OF THESE PARTS MAY COME PRE-INSTALLED

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
36	011-0407018	3/8"-16UNC X 3.75" HHB (WZ)	12
37	011-0107050	1/2"-13UNC X 3.75" HHB (WZ)	4
38	012-0104008	3/8"-16UNC THIN NYLOCK NUT (WZ)	18
39	012-0304011	1/2"-13UNC THIN NYLOCK NUT (WZ)	4
48	019-0002002	CLOSED END GRIP Ø2.00"	2
49	016-0201029	Ø2.00" END CAP .06" WALL (BLACK)	2
50	026-01X2536	FOOT PEG ASSEMBLY	1
51	013-0602002	3/8" FLAT NYLON WASHER	2



ABBREVIATION LISTING

BZ = Black Zinc


WZ = White Zinc

FHCS = Flat Head Cap Screw

BHCS = Button Head Cap Screw


SHCS = Socket Head Cap Screw


HHB = Hex Head Bolt





BOLT SIZING CHART


(CONTINUED)














WASHER SIZING CHART 013-0102026 1/2" FLAT WASHER LARGE, USS, 34mm 013-0102004 5/16" FLAT WASHER LARGE, USS, 22mm 013-0002003 1/4" 013-0002004 013-0402005 013-0102003 3/8" FLAT WASHER LARGE, USS, 25mm 1/2" FLAT WASHER SMALL, SAE, 27mm 3/8" FLAT WASHER FLAT WASHER SMALL, SAE, 13mm SMALL, SAE, 21mm 013-0402007 3/8" FLAT WASHER 013-0102028 3/8" 013-0102019 1/4" LOCK WASHER 013-0102020 3/8" LOCK WASHER 013-0102018 1/2" LOCK WASHER 014-0018001 1/2" LONG SPACER 22mm O.D. **CURVED WASHER** 026-01M0238 2" ALUMINUM FLATHEAD CAP 016-0009003 013-0003002 1" SHIM WASHER 3/8" FENDER WASHER 013-0003004 026-01PL151 1 1/16" **PLASTIC 1 1/16**" FENDER WASHER FENDER WASHER 014-0018002 1" LONG SPACER





MAINTENANCE SCHEDULE

ROUTINE	COMMERCIAL MAINTENANCE	HOME MAINTENANCE	LATEST DATE ENTRY
Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack Pins	DAILY	WEEKLY	
Clean; Upholstery	DAILY	WEEKLY	
Inspect; Cables or Belts and their tension	DAILY	WEEKLY	
Inspect; Accessory Bars, and Handles	WEEKLY	3 MONTHS	
Inspect; All Decals	WEEKLY	3 MONTHS	
Inspect; All Nuts and Bolts, Tighten if needed	WEEKLY	3 MONTHS	
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS	
Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	MONTHLY	3 MONTHS	
Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	MONTHLY	3 MONTHS	
Clean and Wax; All Glossy Finishes	6 MONTHS	YEARLY	
Repack with Grease; Linear Bearings	6 MONTHS	YEARLY	
Replace; Cables, Belts and Connecting Parts	YEARLY	3 YEARS	

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.



HOIST FITNESS SYSTEMS GENERAL MAINTENANCE INFORMATION

Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

- *Check all pieces for signs of visible wear or damage.
- *Check springs in snap hooks and pull-pins for proper tension and alignment.
- *If the spring sticks or has lost its rigidity, replace it immediately.

Upholstery:

- *To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.
- *Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.
- *Replace ripped or warn upholstery immediately.
- *Keep sharp or pointed objects clear of all upholstery.

Decals:

*Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

Nuts and Bolts:

- *Inspect all nuts and bolts for any loosening and tighten if needed.
- *Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

Anti-Skid Surfaces:

*These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

Belts and Cables:

- *Hoist uses only high quality belt, and mil-spec cables.
- *Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.
- *While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.
- *Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.



GENERAL MAINTENANCE INFORMATION

(CONTINUED)

Belt and Cable Tension:

*Referring to the Owners Manual, when belts or cables are used check all bolts attachments to be sure they are properly attached.

*Check slack in cables and re-adjust cable tension if needed.

Seat Sleeves, Guide Rods:

*Wipe down adjusting tubes with a dust free rag before applying lubricant.

*Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

Linear Bearings:

*Referring to the Owners Manual carefully dis-assemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

PLEASE KEEP THIS FOR YOUR RECORDS



WEIGHT TRAINING TIPS

Always consult your physician before starting any exercise program. To be successful in your exercise program, it is important to develop an understanding of the basic principles of strength training. Now that you have your HF4170 HOIST® Fitness System, it is only natural that you want to get started immediately. First, determine a set of realistic goals and objectives for yourself. By deciding on an exercise plan that is right for you prior to starting, you will contribute significantly to your success.

Warm up properly before engaging in weight resistance training. Stretching, yoga, jogging, calisthenics or other cardiovascular exercise can help prepare your body for the heavier workload of lifting weights.

Learn how to perform the exercise correctly before using heavy weight. Correct form is important to avoid injury and to ensure that you work the proper muscle groups.

Know your limitations. If you are new to weight training or are embarking on an exercise regimen after a long layoff, start slowly and build foundational strength over a longer period of time.

Pay attention to your breathing. Exhale when you exert is a general rule of thumb. Never hold your breath.

Enjoy your HF4170 HOIST Fitness System!



Exercise Totals Date S $\mathbf{R} | \mathbf{W}$ $|\mathbf{R}|\mathbf{W}|$ \mathbf{S} $|\mathbf{R}|\mathbf{W}$ \mathbf{S} $|\mathbf{R}|\mathbf{W}$ $|\mathbf{R}|\mathbf{W}$ \mathbf{S} $|\mathbf{R}|$ \mathbf{S} R W \mathbf{S} $|\mathbf{R}|\mathbf{W}$ $|\mathbf{R}|\mathbf{W}$ \mathbf{S} RW R RW

WEIGHT TRAINING EXERCISE LOG

S = Sets R = Repetition per set W = Weight used

HOIST FITNESS SYSTEMS LIMITED LIFETIME WARRANTY

Hoist Fitness Systems warrants this product to the **original purchaser** to be free from defects in workmanship and/or materials under normal use or service. If at any time a component part is defective, Hoist Fitness Systems shall repair or replace it (at Hoist Fitness Systems option) within a reasonable period of time. This warranty does not cover costs of removal. transportation or reinstallation. This warranty shall not apply if the defect was caused by misuse, neglect or normal wear and tear

WARRANTY CLAIMS. All claims require: Model number, Serial number, Date of installation, and any information supporting the existence of the alleged defect.

To complete Warranty Registration visit: www.HOISTFITNESS.com and click on the Warranty Registration link

Starting from the original date of purchase, normal wear and tear shall be considered as the following:

COMMERCIAL USE: All malfunctions of upholstery, grips, paint, and chrome that occur after one year; all malfunctions of electronic components, belts, or cables after one year; all malfunctions of pulleys, bearings, or bushings that occur after five years. The frame and all welded components are warranted for the life of the product.

HOME USE: All malfunctions of grips, paint, and chrome that occur after ten years; all malfunctions of electronic components, belts, cables, or upholstery that occur after ten years; all malfunctions of pulleys, bearings, or bushings that occur after ten years. The frame and all welded components are warranted for the life of the product.

PLEASE NOTE THAT NOT ALL HOIST PRODUCTS ARE MADE FOR COMMERCIAL USE.

Refer to the instructions page of your owners manual or consult with you fitness product dealer to establish if a product is made for commercial use or not. Using a non-commercial product in a commercial setting can result in serious injury or death!

Hoist Fitness Systems sole responsibility shall be to repair or replace the component within the terms stated above. Hoist Fitness Systems shall not be liable for any loss or damage of any kind including any incidental or consequential damages resulting, directly or indirectly from any warranty expressed or implied or any other failure of this product.

WHAT IS NOT COVERED BY THIS WARRANTY

Hoist's sole obligation under this warranty is limited to either repair or replacement of parts, subject to the additions below. This warranty neither assumes nor authorizes any person to assume obligations other than expressly covered by this warranty.

NO CONSEQUENTIAL DAMAGES. Hoist is not responsible for economic loss; profit loss; or special, indirect, or consequential damages.

WARRANTY IS NOT TRANSFERABLE. This warranty is not assignable and applies only in favor of the original purchaser/user to whom delivered. Any such assignment or transfer shall void the warranties herein made and shall void all warranties, expressed, implied or statutory, except the one (1) and five (5) year warranties described above. These warranties are exclusive and in lieu of all other warranties, including implied warranty and merchantability or fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof.

TRANSPORTATION COSTS. Hoist will accept parts covered under this warranty freight collect, provided that shipment has received prior approval. Hoist is not responsible for any other transportation costs, but will ship freight collect parts either repaired or replaced under these warranties.

Hoist Fitness Systems
9990 Empire St. #130
San Diego, CA. 92126
(800)548-5438
PLEASE KEEP THIS FOR YOUR RECORDS

